

Montaje para cupula**Nota:**

No apriete todos los tornillos hasta que no estén completamente alineadas todas las perforaciones con respecto a los puntos de sujeción.

Antes de realizar la instalación, verifique todo el manual e identifique que las partes y las piezas estén completas.

Herramientas:

Kit llaves hexágonas

**Kit Instalado****Instalación**

1- Retire la tornillería ubicada en la parte superior del faro de la motocicleta indicada en la imagen.

**El Kit Contiene:****CUPULA**

Cantidad:

1

2- Instale la cupula con la tornillería original de la motocicleta.

Al terminar la instalación de las partes, verifique que estén alineadas y que toda la tornillería esté debidamente apretada; reajuste todos los tornillos.

Assembly Instructions for windshield



Note :

Do not tighten the screws until they are completely aligned with the holes.
Before the installation, please verify through the manual that all pieces and parts are complete.

Tools Required:

Hex Allen Wrench Set



Assembled kit



Installation

1- Remove the fasteners located on the upper part of the motorcycle headlight indicated on the image



Parts included:

WINDSHIELD



Quantity

1

2- Install the windshield with the original motorcycle fasteners

After the installation of the parts, please check that they are aligned and that all the hardware is properly tightened